

## **DRY TRANSFER PAPER**

Change the printer settings on your computer to give a mirror image. You may have to search the “properties” window but you will eventually find this setting.

Print on the blank dull unlined side of the paper with an inkjet printer, using the “photo” or “best” setting.

Allow plenty of time for it to dry, as the ink will not be absorbed quickly.

With a scissors, trim the paper roughly around the image, in order to leave a minimum of unprinted paper.

Set your iron to the hottest setting or “cotton” temperature, about 350’-375’ F. The fabric should be absorbent, like cotton or a cotton/synthetic blend and should be white or light colored fabric that is pre-washed.

Iron the fabric briefly to flatten it. While the fabric is still warm, put the transfer paper in place, face down.

Iron the image (no steam) onto the fabric, taking about 15-20 seconds per section to transfer the image, moving the iron constantly to all parts of the paper starting in the middle and working toward the end to remove bubbles. Use firm, steady pressure.

Heat the entire surface again using a circular motion. Wait 5 seconds then peel the paper backing off while hot for a matte finish or let cool two minutes and peel for a glossy finish. Color retention is usually better with the hot peel method.

The transfer will feel stiff but will soften with washing. Always wash inside out in cold and do not use bleach or detergents containing whiteners, brighteners or bleach. Tumble dry on air or low setting immediately after washing. The ink can run if left to air dry.

If you have any questions, please feel free to contact us.

**ROCKLAND COLLOID LLC**  
[www.rockaloid.com](http://www.rockaloid.com)